

# Fittings

## Eccentric



**SFA68**

## Concentric



**SFA66**

# Pump Adapters

**PIPE THREADS to TUBING.** These fittings permit the use of Sure-Flo suction fittings on any pump with threaded intakes from 2" to 10". Made from new standard pipe with heavy gauge steel tubing welded to it. The fitting is then hot dipped galvanized. Frequently the suction line should be at least one size larger than the pump inlet. When the tubing size is more than 1" greater than pipe size, the fitting is eccentric. **Eccentric** adapters should be installed straight side up, as pictured, to avoid air pockets from forming.

Part No.	Male Pipe Size	OD Tube Size	Concentric (C) Eccentric (E)	Weight lbs.
SFA152	1½"	2"	C	1.5
SFA22	2"	2"	C	2.5
SFA23	2"	3"	C	2.0
SFA253	2½"	3"	C	3.0
SFA33	3"	3"	C	4.0
SFA24	2"	4"	E	3.0
SFA254	2½"	4"	E	3.5
SFA34	3"	4"	C	3.5
SFA44	4"	4"	C	4.5
SFA35	3"	5"	E	5.5
SFA45	4"	5"	C	4.5
SFA55	5"	5"	C	8.0
SFA36	3"	6"	E	6.5
SFA46	4"	6"	E	8.0
SFA56	5"	6"	C	8.0
SFA66	6"	6"	C	9.0
SFA48	4"	8"	E	10.5
SFA58	5"	8"	E	11.5
SFA68	6"	8"	E	13.5
SFA88	8"	8"	C	14.5
SFA610	6"	10"	E	18.5
SFA810	8"	10"	E	19.5
SFA1010	10"	10"	C	24.5

# Couplers

For joining two pieces of irrigation tubing with an air tight suction joint. This fitting is made from three aluminum castings and is sealed by the compression of two rubber gaskets. Easily and quickly tightened without damage to the tubing. Light in weight and free from rust. Tubing must be supported on both sides of the coupler.



**SFC6**

Part No.	OD Tube Size	Weight lbs.
SFC2	2"	2.5
SFC3	3"	3.0
SFC4	4"	4.0
SFC5	5"	5.0
SFC6	6"	5.5
SFC8	8"	7.0
SFC10	10"	9.5