

Elbows

Sure-Flo aluminum elbows are sealed by the compression of a rubber gasket which is ample in size to assure a seal without excessive tightening. The elbow may be connected and disconnected repeatedly without replacement of the gasket.

| Part No. | OD Tubing Size | Type | Weight lbs. |
|----------|----------------|------|-------------|
| SFE92 | 2" | 90° | 4.0 |
| SFE93 | 3" | 90° | 5.0 |
| SFE94 | 4" | 90° | 7.0 |
| SFE95 | 5" | 90° | 8.5 |
| SFE96 | 6" | 90° | 10.5 |
| SFE98 | 8" | 90° | 14.5 |
| SFE910 | 10" | 90° | 23.0 |
| SFE42 | 2" | 45° | 3.5 |
| SFE43 | 3" | 45° | 4.5 |
| SFE44 | 4" | 45° | 6.0 |
| SFE45 | 5" | 45° | 7.0 |
| SFE46 | 6" | 45° | 9.0 |
| SFE48 | 8" | 45° | 12.0 |
| SFE410 | 10" | 45° | 17.0 |

Fittings



SFE94



SFE44

Klamplox

Designed for Sure-Flo OD compression type foot valves and fittings, Klamplox flanges provide an extra secure connection. The flange is made as a two piece unit which clamps on the tubing and prevents it from being pushed out of the fitting under pressure. A separate aluminum gasket-seal-ring assures uniform pressure against the gasket to prevent leakage. Not more than 10 foot pounds of torque should be applied to the clamp bolts or flange bolts to prevent breakage of the aluminum castings



Maximum Pressure Ratings:

4"-150 PSI 5"- 125 PSI 6"-100 PSI 8"-100 PSI

Foot Valves



SFKV6

Couplers



SFKC6

Elbows



SFKE44