

Fittings



5-48GO



4-48GO Assy



SFTP6

Gun Outlets

Universal Attachable Outlets

Available with 2½" riser pipe threads and for 4", 5", or 6" O.D. pipe. Simply clamp on the pipe with Permatex under the top half and then cut out the pipe with a hole saw.

Small "Guns" may be used on this sturdy outlet. The base is drilled for attaching a board for support of the sprinkler. If the gun has a larger opening than 2½", this may be bushed down to fit.

The usual procedure is to provide a number of outlets, each with a gate valve, and then to move the gun or guns from outlet to outlet along the line. This method saves much time and labor and permits continuous operation of the pump, if one extra gun is available.

May be attached to full lengths of pipe, thus, less expensive than special short lengths with outlets.

For use with tall risers, as for corn, the riser may be supported by a tripod attached to a support board under the outlet and to a band around the pipe.

Part No.	OD Tube Size	Weight lbs.
4-48GO	4"	3.5
5-48GO	5"	4.5
6-48GO	6"	5.5

2½" x 2" cadmium plated steel reducing nipple 7" long

Tubing Plugs

Cast aluminum plugs which can be inserted into aluminum irrigation tubing to make a closure. May be pressed into the tubing, welded into it, riveted, or pinned into place, depending on the requirements. Also may be turned down to provide a looser fit if required.

These castings permit the use of tubing for many special products such as water tanks, fishing rod cases, etc.

Part No.	OD Tube Size	Weight lbs.
SFTP2	2"	.1
SFTP3	3"	.2
SFTP4	4"	.4
SFTP5	5"	.4
SFTP6	6"	.5
SFTP8	8"	2.0